





Up-Down 1x2 Configuration



Up-Down 1x2 Configuration

## • FAQ

**Q:** TV displays with black borders around the edge:

**A:**1) Adjust the display ratio with the mode switch button;

2) Set TV to full screen mode(full pixel display).

**Q:** the TV shows "No signal"

**A:**1) Please check whether there is a HDMI signal input;

2) Try to replace high quality or shorter HDMI cables

3) Try to reduce the resolution of signal source.

## • SPECIFICATION

Item	Description
HDMI signal	HDMI1.3, Full compatible with HDCP1.2
Input port	1×HDMI
Output port	2×HDMI
Audio format	PCM
HDMI resolution	480i@60Hz, 480p@60Hz , 576i@50Hz , 576p@50Hz , 720P@50/60Hz,1080p@50/60Hz
Working temperature	0-60°C
Power supply	12V /2A
Power consumption	<10W
Product dimension	214(L)x108.6(W)x25.5(H)mm
Weight	600g
Color	Black

## Disclaimer

The product name and brand name may be registered trademark of related manufactures. ™ and ® may be omitted on the user manual. The pictures in this user manual are just for reference. The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. We reserve the rights to make changes without further notice to a product or system described herein to improve reliability, function or design.

## HDMI 1×2 Video Wall Controller

### User Manual

